

Thermal Scout

By Mike Chapman
March 1999.

The fuselage at A should be 1 or 1.5 mm deeper than position B.

Dihedral 50mm

Front view.

3 mm Tail tilt.

Round off all the edges.

Add Plasticine to obtain correct balance.

Fuselage 5 mm Hard Balsa.

< Grain >

Total fuselage length approx' 367 mm

Spruce 2mm x 5mm

Leave this centre section flat.

Sand the fuselage to this shape.

Glue the Tailplane here. (Use Cyano)

Fin position.

Tail
1.5 mm Med/Soft balsa

< Grain >

Thin the rear edges of the Fin and Tail to .5 mm.

Fin
1.5 mm balsa

Apply 3 coats of thinned Non-Shrinking Dope. (sand between coats)

High Point

< Grain >

Left wing shown.

Wing

5 mm Medium/Soft balsa

Taper this edge.

5 mm finger support r/h side only.

Cut out here, r/h side only.

Finger support as seen from the rear.

This plan was supplied by :-
F4B Scale Magic
www.f4bscale.co.uk